Key digibal' 🖊

Key Digital 4K AV over IP Encoder/Decoder Unit and System Configuration Procedure

This procedure documents building a Video over IP system using Key Digital 4K AV over IP Encoders and Decoders: KD-IP922-II, KD-IP922, KD-IP822, KD-IP1022.

A less detailed video of the setup procedure can be found <u>HERE</u>

Before proceeding, you must configure your network switch according to the <u>AVoIP Verified</u> <u>Network Switcher Setup Guide</u>

Setup Steps:

- 1. Define System with KDMS Pro System Builder
- 2. (Optional) Customize Unit and System Settings
- 3. Configure Equipment
- 4. Final System Verification

Needs:

- 1. Encoders 1 per video source
- 2. Decoders 1 per video display
- 3. Verified Network Switch Configured according to VNS Setup Guide
- 4. PC with Key Digital Management Software (KDMS) Pro
- 5. USB Data Cable Included with Encoders & Decoders
 - a. KD-922-II Series: USB A to B
 - b. KD-IP822, KD-IP922, KD-IP1022 Series: USB A to Micro
- 6. Completed Unit Configuration form or other unit IP address and naming plans
- 7. Video Source at least one
- 8. Video Display at least one



Configurations for each ENCODER (source) unit Use this subnet: _______ and choose IP addresses for me. Do NOT use the following reserved IP addresses: 192.168.1.1, 192.168.1.50, 192.168.1.90, 192.168.1.100, 192.168.1.150, 192.168.1.200

Group ID	Main IP Address	Video IP Address	Brand (If using KD-App Display Control)
1	192.168.1.5	192.168.1.6	Select
2	192.168.1.7	192.168.1.8	Select
3	192.168.1.9	192.168.1.10	DirecTV H/HR
	Group ID 1 2 3	Group ID Main IP Address 1 192.168.1.5 2 192.168.1.7 3 192.168.1.9	Group ID Main IP Address Video IP Address 1 192.168.1.5 192.168.1.6 2 192.168.1.7 192.168.1.8 3 192.168.1.9 192.168.1.10

Configurations for each DECODER (display) unit

Do NOT use the following reserved IP addresses: 192.168.1.1, 192.168.1.50, 192.168.1.90, 192.168.1.100, 192.168.1.150, 192.168.1.200

Device Name	Group ID	Main IP Address	Video IP Address	Included in video wall?	Brand (If using Display Cor	KD-App htrol)
A - Left	1	192.168.1.11	192.168.1.12	Yes	Samsung	*
A - Right	2	192.168.1.13	192.168.1.14	Yes	Samsung	~
Room B	3	192.168.1.15	192.168.1.16		Samsung	*

Key digital

- 1. Define System with KDMS Pro System Builder
 - A. Open KDMS Pro, choose AVoIP System -> Build Via USB
 - B. Name System
 - C. Define System Type
 - Choose the best fit for the equipment on hand (IP922/822 OR IP1022)
 - D. Define number of Inputs
 - E. Define number of Outputs

1.Switcher Name	SYSTEM NAME							
3.Number of Inputs: 2								
5.Starting Encode	er System ID: 1							
7.Starting Encoder IP Address:								
	192.168.1.51							

- F. Pick starting Encoder IP Address
 - 1. IP addresses will count up from this address alternating between main and video address.
 - 2. Each device is also assigned a unique ID number that is used for switching purposes, which corresponds to Input number in the system
 - 3. Generic names are also assigned to each unit
- G. Pick starting Decoder IP Address
 - 1. IP addresses will count up from this address alternating between main and video address. Each device is also assigned a unique ID number that is used for switching purposes, which corresponds to Output number in the system
 - 2. Generic names are also assigned to each unit

7.Star	ting E	incode	er IP Address: 192.168.1.51	8.Starting Decoder	IP Address: 192.168.1.151
	with E	xisting	g File: 322/IP 1022 Encoders):	Import Sy:	stem Save Changes
2	N	ID	Main IP	Video IP	Input Name
	1	1	192.168.001.051	192.168.001.052	Input 1
\checkmark	2	2	192.168.001.053	192.168.001.054	Input 2
\checkmark	3	3	192.168.001.055	192.168.001.056	Input 3
\checkmark	4	4	192.168.001.057	192.168.001.058	Input 4
\checkmark	5	5	192.168.001.059	192.168.001.060	Input 5



KD-IP922/IP822

192.168.1.151

2

1

2.Switcher Type:

4.Number of Outputs:

6.Starting Decoder System ID:

8.Starting Decoder IP Address:

2. (Optional) Customize Unit and System Settings

- A. After initial setup, device names and IP addresses can be adjusted by clicking their respective fields.
- B. For Adding Video
 Walls, use the section of the dialogue at the top right corner of the window.

Key digital'

Video W	/alls:			Number of	Video Walls:	0
	VW ID	DEC Start ID	Width	Height	Video Wall Na	me
<						>

- 1. Use the "number of video walls" field to specify how many video walls will exist in the final system
- 2. Using the device ID, enter the first Decoder included in each video wall, AKA the top-left decoder (video walls go left to right from the top down).
- 3. Define the width and height of each video wall using the "Width" and "Height" fields

Video	Walls:			Number of	Video Walls: 1
~	VW ID	DEC Start ID	Width	Height	Video Wall Name
\checkmark	1	1	2	2	Video Wall 1
<					>

[www.keydigital.com]

- C. Fields with invalid or conflicting settings will be highlighted red. Highlighted fields must be resolved before continuing.
 - 1. Case 1: Conflicting IP Addresses

Key digital"

Inputs (IP922/IP822/IP 1022 Encoders):						Outputs (IP922/IP822/IP1022 Decoders):							
	Ν	ID	Main IP	Video IP	Input Name	$\mathbf{\nabla}$	Ν	ID	Main IP	Video IP	Output Name		
\checkmark	1	1	192.168.001.151	192.168.001.052	Input 1	\checkmark	1	1	192.168.001.151	192.168.001.152	Output 1		
\checkmark	2	2	192.168.001.053	192.168.001.054	Input 2	\checkmark	2	2	192.168.001.153	192.168.001.154	Output 2		
\checkmark	3	3	192.168.001.055	192.168.001.056	Input 3	\checkmark	3	3	192.168.001.155	192.168.001.156	Output 3		
\checkmark	4	4	192.168.001.057	192.168.001.058	Input 4	\checkmark	4	4	192.168.001.157	192.168.001.158	Output 4		
\checkmark	5	5	192.168.001.059	192.168.001.060	Input 5	\checkmark	5	5	192.168.001.159	192.168.001.160	Output 5		

2. Case 2: Invalid Video Wall (IE: overlapping video walls, or video walls that are specified to use decoders that don't exist in the system)

Video	Walls:			Number of	Video Walls:	1]	
V	VW ID		DEC Start ID	Width	Height	Video Wall N	ame	
\checkmark	1		5	2	2	Video Wall 1		l
<							>	
Outpu	its (IP	922/IP	822/IP 1022 Decoders)	:				
◄	Ν	ID	Main IP	Video IP		Output Name	e	
\checkmark	1	1	192.168.001.151	192.168.0	01.152	Output 1		
\checkmark	2	2	192.168.001.153	192.168.0	01.154	Output 2		
\checkmark	3	3	192.168.001.155	192.168.0	01.156	Output 3		
\checkmark	4	4	192.168.001.157	192.168.0	01.158	Output 4		
\checkmark	5	5	192.168.001.159	192.168.0	01.160	Output 5		

3. Configure Equipment

Key digital'

A. After confirming all fields match the system design and that all invalid fields are resolved, click the "Start" button in the bottom right corner of the window.

IP1022	/IP92	2/IP82	22 Switcher Configura	ation Tool								
1.Swi	tcher I	Name:	SYSTEM NAME	2.Switcher Type:	KD-IP922/IP822 🗸	Video	Walls	:			Number	of Video Walls: 0
3.Nun	nber o	f Inpu	ts: 5	4.Number of Outp	outs: 5		vw	ID	DEC Start ID	Width	Height	Video Wall Name
5.Sta	rting E	incode	r System ID: 1	6.Starting Decode	er System ID: 1							
7.Sta	rting E	incode	r IP Address:	8.Starting Decode	er IP Address:							
		Γ	192,168.001.051	7	192, 168,001, 151							
		L										
Work	with E	xisting	; File:									
SYST	EM N/	AME.a	SC	Import S	System Save Changes	<						>
Toput	- (100)	22/100	22/TD 1022 Encoderaly			Outer	.t. (10	022/0		л.		
Input	s (IP9	22/180	Main ID	Midae ID	law d Nama	Outpu	ILS (IF	922/11	Pozz/IP 1022 Decouers	y: Mater ID		Output Name
	IN .		IVIAIN IP	VIGEO IP	Input Name		IN			Video IP	004 450	
	1	1	192.168.001.051	192.168.001.052	Input 1		1	1	192.168.001.151	192.168.	001.152	Output 1
	2	2	192.168.001.053	192.168.001.054	Input 2		2	2	192.168.001.153	192.168.	001.154	Output 2
	3	3	192.108.001.055	192.108.001.050	Input 5		3	3	192.108.001.155	192,108,	001.150	Output 3
	4	4	192.168.001.057	192.168.001.058	Input 4		4	4	192.108.001.157	192.168.	001.158	Output 4
\sim	2	2	192.168.001.059	192.168.001.060	Input 5	\sim	2	2	192.168.001.159	192.168.	001.160	Output 5
<						> <						>
										Cancel F	Remaining	Exit and Re-Scan
									One to One	St	tart	Cancel

Note the check boxes next to each line. Selected check boxes will be configured when clicking "Start". When building a new system, ensure all boxes are checked.

- B. Follow the instructions as they appear onscreen. One-by-one, the software loads to each unit in your system.
- C. Devices can be powered on individually via POE or power supply. Only one device needs to be active at a time, as all configuration is completed over USB.
 All devices are set up sequentially, with all Encoders first, followed by all Decoders.



Request	×	Request	
Please connect the U	SB cable to	Please connect the US	B cable to
KD-IP922/822 E	ncoder 1	KD-IP922/822 D	ecoder 1
Please allow 60 seconds	for unit bootup.	Please allow 60 seconds f	for unit bootup.
Continue Skip	Cancel	Continue Skip	Cancel

- 4. Final System Verification
 - A. If onsite, and the network switch is configured, after each device is configured, they may be installed.
 - B. Once all devices are configured and installed, the system should be running. Use the "Exit and Rs-Scan" button in the system builder window to run a standard KDMS scan.



Or, If KDMS Pro has been closed and re-opened since configuring the system, you may connect the computer to the network switch, open KDMS Pro, and choose SCAN > NETWORK SCAN

C. Use the "All Outputs" button in the control GUI to verify successful video feed for each Encoder / Decoder combination.

