



OpenEye IP Cameras

Module Setup

About:

OpenEye provides clear picture IP cameras ready for any job. All IP cameras may be integrated into Compass with a video and audio feed.

Setup Communication:

OpenEye Cameras are controlled over RTSP on Port 554. In Compass Navigator, please insert IP Address under Device Properties.

Setup in Compass Navigator:

Compass Control requires the credentials to access the IP Cameras Feed. Under the Properties Tab for the OpenEye device, please enter the username and password for the login field. Default login and password will be submitted if not changed.

Setup Complete:

Upload and update project for use.

Control:

Compass Control offers

- OpenEye IP Cameras
 - o Live View
 - Video and Audio
 - Full Screen Mode Available



Key Digital® Systems :: 521 East 3rd Street :: Mount Vernon, NY 10553 Thone : 914.667.9700 Fax : 914.668.8666 Web : www.keydigital.com